



SNAKEBITE™

LOCKING CONNECTOR

INSTALLATION INSTRUCTIONS

**PART# LSC1030C-* /
LSC1230C-* /
LSC1430C-***



ONE-TIME USE ONLY. MAKE SURE WIRES ARE INSERTED COMPLETELY BEFORE TWISTING TO LOCK.
Do not use with stranded wire.

1. To assist with strain relief, twist wires together approximately 8" from the connector.
2. DO NOT strip insulation from wire.
3. Connector is gauge specific; Verify wire gauge matches connector gauge.
4. Insert wires into holes fully so they are visible in the clear cap.
5. Twist connector CLOCKWISE until locked.

