



COBRA™ HYDRANT FLANGE

ACCESS POINT

INSTALLATION INSTRUCTIONS

PART# HYDFL

1. Using existing hydrant hardware, mount Cobra Hydrant Flange to the hydrant base (clear of nozzle caps). **** Only use the washer when existing hydrant bolt is 1/2".
2. Remove gray PVC adapter from Cobra.
3. Set Cobra on top of hydrant flange.
4. Firmly screw PVC adapter into Cobra from under hydrant flange.

