



MINI COBRA™

ACCESS POINT FOR GAS

INSTALLATION INSTRUCTIONS

PART # MCGR-0.5--*****

(** denotes gauge, *** denotes riser clip option)

1. ATTACH PREWIRED MINI COBRA TO RISER CASING
 - a. Position Mini Cobra to desired height.
 - b. If Riser Clip is attached to housing, snap Riser Clip onto Riser Casing.
 - c. If no Riser Clip, attach housing to Riser Casing with zip tie or other means.
2. CONNECT TRACER WIRES - connect the tracer wire from the Mini Cobra to the tracer wire in the trench using a waterproof locking connector designed for direct bury applications (not included).
3. DRIVE GROUND ROD - at grounding location, pound ground rod into soil using a hammer or mallet. Leave minimum 2 feet of slack wire for backfilling and/or ground settling.

