



PIPE BURST CONNECTOR IN-LINE SPLICE

INSTALLATION INSTRUCTIONS

PART# SC-PB-01



1. Prior to stripping wire, slide heat shrink onto wire
2. Strip wires 5/8"
3. Loosen set screws on connector with Allen wrench
4. Place stripped wires into ends of connector
5. Tighten set screws with Allen wrench; do not over torque
6. Position heat shrink on connector; heat evenly with heat gun or handheld torch until sealed

Do not reuse.

