



PIPE BURST CONNECTOR THREE-WAY

INSTALLATION INSTRUCTIONS

PART# SC-3WPB

1. Strip wires 9/16"
2. Loosen set screws on connector
3. Align conductors
4. Place stripped wires into holes; use center hole for service line
5. Tighten set screws with Allen wrench; do not over torque
6. Firmly place connector in gel-filled cap and snap shut so all exposed wires and connector are covered

Do not reuse.

