



# TRACER WIRE

## INSTALLATION INSTRUCTIONS

### **CAUTION: Wire may be subject to spring release**

When dispensing Copperhead tracer wire from the spool, it is highly recommended to anchor the cut end of the wire to a stationary object (riser, service tee, post, etc.). Dispense the wire using two hands. Use one hand to hold the spool via the spool arbor with a rod or a loop of wire, and one hand to counter form (straighten) the wire as it dispenses from the spool. If you follow this procedure, the wire will lay flat in the trench.

