



BoaBox™ WATER ACCESS POINT

INSTALLATION INSTRUCTIONS

Patent No. 11,814,824

1. Remove new or existing curb box top and dig 10" from finished grade.
2. Standpipe can be 4" – 5" below finished grade. Adjust BoaBox™ to final grade.



3. **BoaBox should be supported from the ground, not the curb box stand pipe.**
4. Bring tracer wire and ground rod wire up through tracer/ground wire compartment from the bottom.
5. Leave at least 12" of excess wire (tracer wire compartment can accommodate 24" of excess wire).
6. **Backfill and pack around BoaBox BEFORE HOOKING WIRES TO TERMINAL.**



7. Hook up tracer wire and ground rod wire to terminals.
 - a. Strip ends of tracer wire and ground rod wire 3/8" (tracer wire and ground rod sold separately).
 - b. Put 90° bend on stripped wire ends, place into holes in terminals, and tighten set screws to secure wire in terminals.
 - c. **Ground rod wire must connect to the terminal post that can be unhooked from jumper.**
 - d. Apply dielectric gel (provided) to the wire connections.
8. Snap terminal box into BoaBox by pushing in or tapping in with rubber maul, **not metal hammer.**
9. Replace pentagon plug if previously removed.

